

**FINGERTEC**



# **AUTOMATIC TIME**

**SYNCHRONIZATION BY TCMS V2 TO FINGERTEC® READERS**  
SUGGESTIONS & SOLUTIONS FOR TCMS V2


You can add in this feature into your current TCMS v2, so TCMS v2 will always synchronize the time of connected FingerTec readers every time when it starts running. Please follow the steps as below:

Step 1

Download and Extract the NT Service.zip




Please try to unzip this file by using any extracting agent, such as WinZip. You will see these 4 files after the unzip or extracting process.



Step 2


Copy files and paste into TCMS V2 folder



You will require to copy and paste all these 4 files into TCMS v2 folder. Please kindly take note; you will do this step after you shut down TCMS v2 program.

Step 3

Start to use this feature



Select Set Terminal Date and Time to see this new feature. Now you can enter the timer to enable this time synchronization to function to each connected FingerTec reader. The process will start when the computer is powered on.