

START

1
**HARDWARE
INSTALLATION**

*Refer to Hardware Manual



FingerTec® Reader Installation

2

**HARDWARE
SETTINGS**

*Refer to Hardware Manual



User RFID Card Enrollment

3



Communication Settings

4

**SOFTWARE
INSTALLATION**

*Refer to TCMS V2 1 manual



TCMS V2 Installation

11



Exporting Data Into Third Party Software
(Payroll Or Others)

* Skip this step if you are
NOT using third party software

12



View & Print Report

10



Download Data From
Reader To Computer

**DAILY
OPERATION**

*Refer to TCMS V2
Manual



FINGERTEC

Timeline 100

TIME ATTENDANCE RFID CARD SYSTEM

Quick Start Guide

For other languages, please refer to <http://user.fingertec.com>

**SOFTWARE
SETTINGS**

*Refer to
TCMS V2 Manual

5



TCMS V2 Initial Settings

8



Assign Users To
Working Group

8



Settings Of Working
Time & Group

7



User Information

Fill up user information in TCMS V2

6



Download User ID + Card ID

Download User ID + Card ID from reader
to computer installed with TCMS V2

www.fingertec.com