

## Connecting More Than 2 Fingerprint Terminals (Create Instance)

In some instances, you may need to have more than one BioBridgeSDK component present. To illustrate further, view the example below. List1 contains one BioBridgeSDK component. To detect a second fingerprint terminal you'll need to add one more BioBridgeSDK component.

	(2.3 (23) HT   207 8-8 48 48	을 찾 향 한 번 년 역				
arml.c+ Form1.cs [Design]						
Band Rate         115200           Model	Device No 1 Enable / Unicok Door Enable / Deable Device with Timeod 00 Month 0000 Year 00 Minute 00 Second Sync	User Fingerpint Template M Errol No 1100 Fingerpint Template	ariagement Get Template Set Template Delete Template	Get TimeZone Get G TimeZone TimeZone No TimeZone Str Get TimeZone Unlock Group Get Unlock G	Set TimeZone Set G TimeZone 1 Set TimeZone Set Unlock G	
Read User Data Ru Clear User Data O Oear Al Reida Oe Set Last Court 0 External USB Management Elemena	er Log er Admin		0	Booking Days	InidgeSDK	
Flename			Open File	Backup Data	Restore Data	
	Name	TimeZone G TimeZone Info	Record Size	Get User File	Save to File	
Enroll No 1100 Privilege	Paseword					

To add another BioBridgeSDK component, go to **Toolbox -> General -> and drag the BioBridgeSDK Control into** the design view panel.

역 Project2 - Microsoft Visual C# 2008 Express Edit	tion		Statement of the local division of the local
File Edit View Project Build Debug [	Data Tools Window	Help	
	· Ø · B   )	🗸 🗸 🖓 Privile	dge 🚽 🚽 🐄 🞲
해도소리교소리문해요곱	aBa 3-0< 000 00   ≗	Å* &* A* I III I III III III III III	
	-   *** ++ ++   Z	<u>x+ s+ ⊕+  ⊡ ⊡  ⊐  ⊣</u> ⊣⊒  ⊒; =	
All Windows Forms	1		
Common Controls			
E Containers			
🗄 Menus & Toolbars	een Models Functions De	emo Multimedia Demo	
🗄 Data		User Information Management	Group Timezone Management
Components	Connect	Enroll No 1100 Get User Info	Enroll No 1100
Printing	Disconnect	Name	Group No
Dialogs	Set Comm Key	Password Set User Info	TimeZone Info
	Advance		
Pointer	Advance		Get Usergroup Set Usergroup
00X BioBridgeSDK Control	Hestart	Enabled True - Card No.	Get TimeZone Set TimeZone
	No 1	User Fingerprint Template Management	
	Poor Enable /	Enroll No 1100 Get Template	Get G TimeZone Set G TimeZone
	Disable	Finger Index o	TimeZone No 1
	pevice with Timeout	Set Template	The Zone No
		Fingerprint Template Delete Template	
	0000 Var		Get TimeZone Set TimeZone
			Illelade Carrier
	00 Second		Unlock Group
			Get Unlock G Set Unlock G
			4
	List1		BioBridgeSDK
	1		Siddinageobix



You can then change the name of the second BioBridge component in the Properties window, and use this updated name when doing further coding. For example, if you rename it as **BioBridgeSDK2**, your function name should be typed as named as **"BioBridgeSDK2.GetUserInfo"**.

• 💕 🖬 🕼	X 10 18 4	9 · (* · 1	- 24 1	*	- 🥶 Privile	edge			
송 레   ㅠ rm1.cs <sup>-&gt;</sup> Form	≪ <u>a</u>   co ∑ Les [Design]*]	密 南   101	194 994 994	} ∯ ⊕  ⊕ ⊕	9.81 <u>8</u> 1			Properties	DK2 AvRinBrid
BioBridgeSD	K V2 1.028 Demo						O B B	21 (1)	#   E
Main SMC 8	Gm\/orTupe Dama	Color Somen I	Indels Exertions D	Inno Multimedia Demo				E (Application	nSet
Device Conne	ector	Cons Sestar		User Information Manager	ent	Group Timezone Ma	nagement	E (DataBindin	igs)
© IP	COM O	USB Client	Connect	Enroll No 1100	Cat User Infa	Enroll No 1	100	(Name)	axBioBrid
IP Address	192.168.1.201		Disconnect	Name	Oet Oper mito	Group No		AccessibleD	lam
Port	4370		Set Comm Key	Password	Set User Info	TimeZone Info		AccessibleR	lole Default
Comm Key	0		Advance	Privlege	Delete User Info	Get Usersmun	Set Lineman p	AllowDrop	False
Comm Port	1		Restart	Enabled True • (	Card No.			Anchor	Top, Left
Baud Rate 115200 Device No Model Unlock Door	Device No	Device No 1	Liner Encempiet Terrolate Management		Get G TimeZone Set G TimeZone	CausesValid	datic True		
	Enable /	Enroll No 1100	Get Template	one Set G TimeZone		ContextMee	nuSt (none)		
Delay (ms)	1000	Disable Devic	e with Times it	Finger Index in	Cet Templete	TimeZone No	No 1	DC	10672091
Time Out (s)	10	CORDER DOTE	o man reneves		Set remplate	TimeZone Str		Dock	None
Device Date a	and Time			Ringerprint Template	Delete Template	[C.17. 7.]		Finger10	0
Date	00 Day 0	00 Month 0	000 Year			Get timeZone	Set ImeZone	GenerateMe	emt True
Time	00 Hour (	00 Minute 0	0 Second			Unlock Group		Location Locked	719, 403 False
Get	Set	iync				Get Unlock G	Set Unlock G	MAC	
General Data	Management	Lat						E Margin E MaximumS	3, 3, 3, 3 ize 0, 0
Read User I	Data Read I	Log				Biob	inugeaUK	MinimumSi	ize 0,0
Clear User D	lata Clear L	.09				0	0 00	Modifiers El Daddina	Private
Clear All Fre	the Clear A	denia.				086	oBridgeSDKP	E Size	100, 50
Contra Par Pa	Cear A					0	0 0	(Name)	