



TIPS FOR FINGERTEC BIOBRIDGE SDK

For computer which has already installed TCMS V2, please ensure that it is TCMS v2.11 and above in order to work well with FingerTec BioBridge SDK. The earlier version of TCMS v2 will not work with FingerTec BioBridge SDK

If you already install FingerTec BioBridge SDK and earlier version of TCMS v2, you will need to upgrade your TCMS to TCMS V2.11. The TCMS upgrade will not affect your current TCMS database.

Followings are the instructions to resolve your issue:

- Please go to your add/remove program to uninstall the FingertecBioBridge SDK.
- After that, please uninstall your FingerTec TCMS V2. (refer to Appendix 1)
- For the latest TCMS Software download, please logon to http://tips.fingertec.com/, (username: fingertec, password: fingertips), under Section D. Download, look for TCMS V2.11
- After finished downloading, please install the TCMS 2.11 (refer to Appendix 1). The installation will not affect your existing TCMS database.
- After installing the TCMS V2, you may install the FingerTec BioBridge SDK. It is done.

Appendix 1 Upgrade from TCMS v2.1.0 to TCMS V2.1.1

Please follow the steps below to upgrade TCMS V2 from version 2.1.0 to version 2.1.1.

Step 1 • Remove the TCMS V2.1.0 by using the Add/Remove Program in Control Panel.







🖬 Add/Remov	e Programs			
12	Currently installed programs:	Sort by: Name	•	
Change or	1 Adobe Reader 7.0.8	Size	55.7MB 🔺	
Programs	avast! Antivirus	Size	36.1MB	
	BitComet 0.70	Size	7.04MB	
2	DigitalPersona Gold Fingerprint Recognition Software 2.5.0	Size	3.33MB	
Add New	🛞 eMusic - 50 Free MP3 offer	Size	140KB	
Programs	🔮 Fingerprint Reader Management Software	Size	7.60MB	
** ¶	🐻 FingerTec TCMS v2.1.0	Size	21.8MB	
	Click here for support information.		L	
Add/Remove Windows	To change this program or remove it from your computer, click Change or Remove.	Change	Remove	
Components	🛃 ICQ Toolbar	Size	512KB	
	🃸 ICQ 5.1	Size	16.2MB	
	🚮 K-Lite Codec Pack 2.72 Full	Size	27.5MB	
	🛃 Macromedia Flash Player 8			
	🚝 Microsoft .NET Framework 1.1	Size	39.0MB	
		-		
		-	Close	
		_	0.000	
A new window will pop up. V2 1.0 and click the Remove				

InstallS	hield Wizard			
FingerTec TCMS v2.1.1 Setup is preparing the InstallShield Wizard which will guide you through the program setup process. Please wait.				
Checking Operating System Version				
	Cancel			

Wait for the remove process to finish.

Step 2 Install TCMS V2.1.1.

Run the setup file from CD or download file.

InstallShield Wizard FingerTec TCMS v2.1.1 Setup is preparing the InstallShield Wizard which will guide you through the program setup process. Please wait. Checking Operating System Version Cancel



E u2.1.1 TectallEbiold Wis-

Installation is in progress.

Change Current Destination Folder Browse to the destination folder.						
Look in:						
<u>E</u> 00KIII.						
📄 tcmsv211		•	E 💣			
Internet Explorer	MSN Messenger	Skyp				
K-Lite Codec Pack	NetMeeting	tcms ^v	/211			
Lavalys	Outlook Express	🚞 Treno	d Micro			
Messenger	ireadernetman	🚞 VIA				
microsoft frontpage	🚞 Real	🚞 Wina	mp			
Microsoft Office	🚞 Sierra Technology	🚞 Wind	ows Media F			
•			F			
Eolder name:			k			
C:\Program Files\tcmsv211\						
tallShield						
	Г		- Current - 1			
		UK	Cancel			

Choose to install into the same folder as TCMS V2.1.0.

This could keep all database of your old TCMS V2.

Click OK to proceed



Installation of TCMS V2.1.1 is in progress.

VI



Click Finish to end the process.

Step 3 → Remove the TCMS V2.1.0 by using the Add/Remove Program in Control Panel.