

## Integrating BioBridge SDK with C# (ActiveX)

Step 1 Select the Windows Application and click OK.

Project types:		Templates:			
Project types: Usual Basic Undows Starter Kits Starter Kits Usual C# Other Project Types		Visual Studio installed ten         Windows Application         Windows Control Library         My Templates         Search Online Templates	Visual Studio installed templates Windows Application Windows Control Library Windows Control Library Search Online Templates		
A project for cre	ating an application v	with a Windows user interface			
ame: WindowsApplication2					
Name:		Settings\Administrator\My Documents\biobridge		~	Browse
<u>N</u> ame: Location:	C:\Documents ar		tion2 Create directory for solution		

## Step 2 Go to Project > Add References

WindowsApplica	tion2 - Microsoft Visual Studio		
	Add Windows Eprin Add Uner Control	great grantery (pep	
oabax 🔸	Add Compagent	Copect Browser	★ X SoldenEglaw - Solder + ¥ X
<ul> <li>All windows For <sup>2</sup></li> </ul>	Add glass		S S S S S S
Containers Menus & Teells	Add Ney Den Orl+Shift+A Add Exating Dans Shift+Ab+A		Goldson WindowsApplication2
Data Components	Exclude From Project	-	# 22 References # 27 References
Dialogs	Add Beference		Program.ca
General	Add Wgb Reference		
There are no usat	Set as Rightup Project	P	
controls in this grai	WindowsApplication2 Properties		
	0	o	Permit as the Properties
Server E. Streeb			Copy to Output Do not copy
Mpd			w Ø X Ouston Tool Na
how output from:	×1.2	[A] 4] (a) [a]	E Misc
			FullPath C/Dooments-and
			Advanced
Bre List 🔳 Output			

Step 3 • Click on the Browse Tab and locate the BioBridge SDK. It is normally located at C\windows\system32\BioBridgeSDK.ocx

Add Reference		? 🔀
.NET COM Projects	Browse Recent	
in iobj iProperties	Add Reference	? 🗙
File name: Files of type: Component	Look jn: is system32 azroles.dll basesrv.dll batmeter.dll batt.dll biol.ocx	BioBridgeSDK.ocx       biokey.ocx       bibsprx3.dll       bibsprx3.dll       bibsprx3.dll       bibsprx3.dll       bibsprx4.dll       bibsprx4.dll       bibsprx4.dll       bibsprx4.dll       bibsprx4.dll       bibsprx4.dll
	File name:         BioBridgeSDK.ocx           Files of type:         Component Files (".dll," tib,".olb,"	Description: Boot Config T Company: Microsoft Corp File Version: 5.1.2600.55 Date Created: 8/4/2004 & Size: 139 KB

## Step 4 After that, go to general on your left hand side and right click and select "Choose Items".

WindowsA	pplication	2 - Micresoft Vi	sual Studio				🛷 WindowsApp
The Edit Ve	vy Project	Build Debug	Data Toole Window C	Community Help			The Edit Weve
a	19.9	X 25 19 10	- mis Circles p	abug 🔄 Any CPU	× (3)	1	- <u>⊡</u> •⊯
	1 17 0	自己用用					1911 to A 31
adbas + All Windows + Containers + Containers + Menus & Ter + Data + Conta - Printing + Dialogs - General	• 0 x Forms strafe sibers	Formi as (Des	gn] StartPaga   CbjactD			<ul> <li>X Solution Capture - Solution</li></ul>	Taabac + All Windows Fi + Containers + Containers + Menus & Taall + Data + Correponents + Correponents + Petition + Dialoge - General
-		1		D		System Drawing	R Pointer
Controls in t Drag an iter text to adu	Show All	5				- D System Windows, Per - D System Jind - Parel Los	IIIX BoBridgeSCK C
boolb	Choose I	Ders				- M Programiza	
	Ranat To	apex.				Solution Explorer Dig Class View	
	Add Tab					Properties + # X	
	Delete Ta	h	0	0		Formiliza File Properties *	
	Rename 1 Move Up	rab				B Advanced Bald Advan	
More Down				Copy to Output Do not copy	Stever L. X1		
output.						• V X Oustom Tool No	Output
Show output from	1		+1 2 1 40 AL	- II		El Misc	Show output from
						FullPath C//Dooments and	
						Advanced	
Bere List 🔳	utput						Berer List 🔳 Out
Beach							Ready



.NET Fr

Step 5 • Select "COM Components" Tab and select BioBridgeSDK con-

Toolbox Items		?
amework Components	COM Components	
9	Path	Library
ctiveSkin 4.3 Control dbanner Class FXOnlineMain Control hixib class	C:\WINDOW5\system32\a C:\WINDOW5\system32\m C:\WINDOW5\system32\Z C:\WINDOW5\system32\in	tskn43.ocx ActiveSkin 4.3 T sdxm.ocx KOnline.ocx Biokey Online(1:N) etsrv\cert tom
oBridgeSDK Control	C:\Program Files\FingerTec	TCMSv2\ BioBridgeSDK A
hilkat Ftp2 OMNSView Class rystal Report Control rystal Report Viewer Co TreeView Control	C:\WINDOW5\system32\ch C:\WINDOW5\system32\ch C:\WINDOW5\system32\ch C:\WINDOW5\system32\ch C:\WINDOW5\system32\ch C:\WINDOW5\system32\ch	nilkaftp2.dll Chilkat Ftp2 2.0.0 omsnap.dll ComSnap 1.0 T rystl32.ocx Crystal Report viewer.dll Crystal Report mocx.dll ctv OLE Control
A 4	mi in the second se	
dgeSDK Control Language: Langua Version: 1.0	ge Neutral	Browse
		DK Cancel <u>R</u> eset

Step 6 The BioBridge SDK component has been added to your project and now you can start calling its functions.

🐓 WindowsApplication	2 - Microsoft Visual Studio	
Pile Edit View Project	Buld Debug Date Pornat Tools Whebw Community Help	
163 · 10 · 10 / 10 / 10	A Ga C + C + C + C + C + D + Debug Any CPU A	197日外国口•.
1911 E & 1 17 0	·自己见现这一些效素的考虑的结果。	
tradox - 9 x 4     Al Wholes Form     Economic Controls     Economic Controls     Contrainers     Whoman & Institutes     Postaine     Postaine     Postaine     Economic     Postaine     Economic     Postaine     Control      Postaine     Control      Postaine     Control     Contro     Control     Control     Control     Control     Contro     Co	Termine (Desemple: Calend forware) + X	Staten Explore Staten + # X
Show I	য় সাজমানার.	actionarganical Actionacian activity of actional action Accessibility of action Accessibility of action Accessibility of action Accessibility
Ready	1 100, 112	5 100 x 50
Batan 1 3 8	ng 📲 🔁 th. 212 🔰 My Consultar 🔁 Microsoft Visu	81 00 00 00 500 PM